TiVo Stream 4k Remote Control USER GUIDE

1. **POWER** turns the TV on or off
2. **GUIDE** takes you to the on-screen Guide
3. **VOL** controls the volume on your TV
4. **TIVO** takes you to main menu
5. **MUTE** turns the sound on or off
6. **CONTROLLER** navigates using **UP, DOWN, LEFT OR RIGHT** areas
7. **BACK** opens the main menu or returns to the previous screen
8. **VOD** go to on video on demand where you can browse, rent or watch movies
9. **NETFLIX** launches the Netflix app
10. **MICROPHONE** for Voice Search
11. **INPUT** selects input for your TV
12. **CH** changes the channels up and down
13. ***'i'*** shows more information about what you're watching
14. **OK** in the center of the Controller, accepts the current section
15. **EXIT** leave app to go to main menu
16. **VOICE SEARCH** find your shows.
17. **APPS** takes you to your apps
18. **NUMBER BUTTONS** Enter numbers (e.g., channel numbers or Parental Control PIN)